

# Plus-X ICRU

---

*Installation and Operation Manual*



## Contents

Introduction .....	1
Front Panel Indicators.....	1
Rear Panel Features.....	1
Network Settings.....	1
Initial Connection Using DHCP .....	2
Initial Connection Without DHCP .....	3
Set a Static IP Address .....	4
Complete the Network Settings .....	5
Connecting the Plus-X ICRU to the ARC Plus.....	5
Using a Status Channel to Monitor the State of a Relay Output.....	6
Connecting Command Channel Outputs .....	6
Pairing Relays .....	7
Relay Diagnostics.....	7
Restoring Factory Configuration .....	8
Uploading New Firmware.....	8
Getting Help .....	8
Warranty .....	8
Appendix A: Specifications .....	9
Dimensions:.....	9
Operating Temperature: .....	9
Humidity: .....	9
Power Requirements:.....	9
Connectivity:.....	9
Channel Capacity: .....	9
Output Types:.....	9

## Introduction

The Plus-X Integrated Command Relay Unit is used to connect site equipment to the ARC Plus. Each Plus-X ICRU connects up to 16 relays or 8 pairs of raise/lower relay outputs. Plus-X ICRU units are connected to the ARC Plus via LAN or WAN. Up to 32 Plus-X devices can be connected to each ARC Plus.


## Front Panel Indicators



Front panel of the Plus-X ICRU

Indicator	State	Description
Power LED	Off	Power is off
Power LED	Green	Power is on
Power LED	Flashing Green	Resetting to factory default settings
Power LED	Amber	No firmware loaded (contact Technical Support)
Power LED	Red	Resetting to factory default settings
Link LED	Green	Connected to ARC Plus
Link LED	Red	No connection to ARC Plus

## Rear Panel Features



Rear panel of the Plus-X ICRU

The Plus-X ICRU provides 8 raise relay outputs (left side of panel) and 8 lower relay outputs (right side of panel). Ethernet and AC power connections and the Master Init button are also located on the rear panel.

## Network Settings

Each Plus-X ICRU must be assigned a static IP address for communication with the ARC Plus remote control system. However, using a dynamic IP address assigned by Dynamic Host Configuration Protocol (DHCP) is an easy way to do initial setup of the Plus-X ICRU. This

document describes the procedure for establishing initial communications with a Plus-X ICRU in a network that supports DHCP and in a network that does not.

The table below lists the firmware version in which DHCP functionality was introduced for the Plus-X ICRU. The table also specifies the default hostname that must be used for initial connection to the Plus-X ICRU when it is installed on a network that supports DHCP.

Plus-X Unit	DHCP Firmware Revision	Hostname*
Plus-X ICRU	1.1.27	PLUSXICRU

\* Hostnames can be used in either upper or lower case.

### Initial Connection Using DHCP

Connect the Plus-X ICRU to your LAN and apply power. If this is the first power-up for a new unit or the first network connection after execution of a master-initialization, the Plus-X ICRU will issue a DHCP request for an IP address. If the network supports DHCP functionality, a dynamic IP address will be assigned to the unit. To access the unit, launch a web browser and enter the hostname from the table above in the browser's address field, followed by the forward-slash symbol as follows: PLUSXICRU/.

The login screen shown below will be displayed.



The screenshot shows a web browser window with the Burk Technology logo at the top. The main heading is "Set the administrator password." Below this, there are three input fields: "Username:" with the value "admin" entered, "Enter Password:" with an empty text box, and "Confirm Password:" with an empty text box. A "Save" button is located below the password fields.

Firmware Version 1.0.30  
© 2014-2019 Burk Technology, Inc. All rights reserved.

Select and confirm a password for the admin account and click the Save button.

**Note:** If the page above is not displayed or the browser indicates that the page cannot be found, it is possible the connected network does not support DHCP. In this case follow the steps outlined in "Initial Connection Without DHCP". Otherwise, log in as shown below and continue to "Set a Static IP Address".

Use the credentials confirmed above to log in when the following screen is displayed.


The image shows a login interface for Burk Technology. At the top, there is a header with the 'BURK TECHNOLOGY' logo. Below the header, there are two input fields: one for 'Username:' and one for 'Password:'. To the right of the 'Password:' field is a 'Log On' button. The entire login area is enclosed in a rectangular border.

Firmware Version 1.0.30  
© 2014-2019 Burk Technology, Inc. All rights reserved.

### Initial Connection Without DHCP

If your network does not support the DHCP protocol, the Plus-X ICRU's request for a dynamic IP address will fail. If this happens, the Plus-X ICRU will assign itself the default static IP address of 192.168.0.100. To access the unit, it will be necessary to connect your PC directly to the Plus-X device using a crossover LAN cable or using a simple Ethernet switch.

In addition, your PC's internal network interface must be set to a static IP address of the form 192.168.0.x. In the Windows Control Panel, search for *Change Ethernet Settings*, then select *Change adapter options* then *Local Area Connection*. Navigate to the Internet Protocol Version 4 (TCP/IPv4) Properties dialog box as displayed below.




Select “Use the following IP address:” and enter an address of the form 192.168.0.x, where x is any value between 1 and 255 except 100 which is the Plus-X default IP address. Also set the subnet mask to 255.255.255.0 as shown above. Check the box “validate settings upon exit” then click *OK*.

Now launch a browser and enter 192.168.0.100 in the address field. You will be prompted as shown in the previous section to provide a password for the admin account, and then to log in to the admin account using the newly assigned password.

### Set a Static IP Address

The first screen displayed after initial login is the *Network Settings* page, as shown below.



Enter a static IP address for this unit as assigned by your network administrator in the *IP Address* box and click *Save*.

*Note: It is important that the assigned static IP address be outside the DHCP address range used by the router to avoid potential conflicts with other DHCP devices.*

If your initial connection was made without DHCP, your PC should now be restored to its prior network settings, and both the PC and the Plus-X device should be connected to the normal LAN.

## Complete the Network Settings

Your browser will be redirected to the login page after the static IP address has been set. If this does not happen automatically, enter the static IP address assigned above in the browser's address field. Log in to the Plus-X ICRU using the admin account.

On this second login, a different *Network Settings* page is displayed as shown below.

**Network Settings**

Name:  An optional name that is displayed on the log in page and the header.

Hostname:  An optional hostname for use on a local network.

IP Address: \*  The static IP address for this unit. (Do not assign within the DHCP range.)

Subnet Mask: \*  The subnet mask associated with the IP address above.

Gateway: \*  The IP address of the router used for connections outside the local network.

ARC Plus IP Address: \*  The IP address of the ARC Plus that communicates with this device.

Link Down

HTTP Port: \*  The port number to use for the web page. By default this is port 80.

Plus-X Port: \*  The port number to use for communication with the ARC Plus. By default this is port 45000.

\* Indicates required field

You will see the IP address you previously assigned. Additional fields must now be completed. It may be necessary to obtain the Subnet Mask and Gateway IP address from your network administrator. It is also necessary to assign the IP address of the ARC Plus unit that will be controlling the Plus-X ICRU.

It is also a good idea to change the hostname from the default value so conflicts will not occur if multiple Plus-X devices of the same model are installed on the network. The default values for HTTP Port and Plus-X Port can most often be accepted.

You may also add a name to the unit that will be displayed on the login page.

Click the **Save** button to activate these settings.

## Connecting the Plus-X ICRU to the ARC Plus

If you have not already done so, install the Plus-X ICRU in the equipment rack. If you wish, you may distribute Plus-X units in multiple racks, or at different locations. To add the channels from the Plus-X ICRU to the ARC Plus:

1. Launch AutoLoad Plus and connect to the ARC Plus site to which the Plus-X unit will be linked.
2. From the Edit menu, selected Plus-X Devices... and click Add.

3. When the Plus-X Device window appears, select Plus-X ICRU from the device type drop-down. Enter a description of the Plus-X unit for your own reference, followed by the IP address and Port, as already configured on the Plus-X ICRU.
4. Check the box marked Map Default Set of Channels to add all channels for this Plus-X unit to the ARC Plus and enter a starting channel number for assignment of these channels in the ARC Plus. If you are not using all channels, or if you do not wish for them to appear in sequential order, you will need to manually map the channels. In this case, leave this checkbox unchecked.
5. Press OK to close the Plus-X Settings window. Press OK to close the Plus-X Devices window.
6. To manually map Plus-X ICRU channels to the ARC Plus, click the Command tabs. Locate an unused channel and click the [...] button in the Source column. This will bring up the Source dialog. Click the Plus-X channel button and choose the Plus-X device and channel you wish to use.
7. Select File>Save to save the changes to the ARC Plus.

### Using a Status Channel to Monitor the State of a Relay Output


The ARC Plus Touch can monitor any Plus-X ICRU relay to determine whether it is energized or de-energized. This is done by assigning the relay state to a status channel in the ARC Plus.

To monitor a relay state with a status channel, follow the steps below:

1. After adding the Plus X ICRU, select the Status Channel tab in Autoload Plus.
2. Locate an unused channel and click the [...] button in the Source column. This will bring up the Source dialog. Click the Plus-X channel button and choose the Plus-X ICRU device and the relay you wish to monitor with that status channel.
3. Select File>Save to save the changes to the ARC Plus.

### Connecting Command Channel Outputs

The Plus-X ICRU allows connection of 8 raise and 8 lower channels. Raise channels connect to the left set of 24 pins on the rear panel and lower channels connect to the right set of 24 pins as shown below:



Closeup of Form C contacts on the Plus-X ICRU rear panel

Each channel has three pins: a pin for common (left), and pins for the normally open and normally closed contacts. Pinouts for raise channels 1-8 and lower channels 1-8 are identified on the chart below.

1	2	3	4	5	6	7	8
C NO NC							

Pinouts for raise channels (left side of Plus-X ICRU rear panel) are identical to the pinouts for lower channels (right side of Plus-X ICRU rear panel).

Attach wiring for each channel using the mating connector blocks supplied in the accessory kit. Secure the wiring using the built-in set screws before attaching the connector block to the appropriate rear panel connector.

### Pairing Relays

The 16 relays on the Plus-X ICRU may be used individually as up to 16 command channels, or in raise/lower pairs (8 channels). To configure the relay behavior, use a web browser to connect to the Plus-X ICRU. Click on the **Configuration** link in the menu bar and click on **Relay Settings** from the sidebar.

Click the **Pair** checkbox in the center column to pair the associated relays (1 and 9, 2, and 10, etc). When paired, the relays will behave as one raise/lower channel. When not paired, each relay behaves independently.

**Relay Settings**

Use the **Pair** checkbox to form a pair of mutually exclusive relays. When one relay in the pair is activated, the other will be deactivated.

Relay	Pair	Relay
1	<input checked="" type="checkbox"/>	9
2	<input checked="" type="checkbox"/>	10
3	<input checked="" type="checkbox"/>	11
4	<input checked="" type="checkbox"/>	12
5	<input checked="" type="checkbox"/>	13
6	<input checked="" type="checkbox"/>	14
7	<input checked="" type="checkbox"/>	15
8	<input checked="" type="checkbox"/>	16

### Relay Diagnostics

The Relay States page of the Plus-X ICRU web interface shows the state of each relay. This page is provided for diagnostic purposes and may be useful during initial setup or troubleshooting. The values on this page are not updated in real time and should not be used for daily operation.

**Relay States**

Relay 1 Off  
 Relay 2 Off  
 Relay 3 Off  
 Relay 4 Off  
 Relay 5 Off  
 Relay 6 Off  
 Relay 7 Off  
 Relay 8 Off  
 Relay 9 Off  
 Relay 10 Off  
 Relay 11 Off  
 Relay 12 Off  
 Relay 13 Off  
 Relay 14 Off  
 Relay 15 Off  
 Relay 16 Off

[Refresh](#)

4.

## Restoring Factory Configuration

To reset the unit to its default configuration, press and hold the MASTER INIT button for three seconds. The Power LED will flash green to confirm the configuration has been reset. Note that restoring the default configuration will reset the unit's password and IP address, requiring the initial configuration steps to be repeated as described at the beginning of this document.

## Uploading New Firmware

Refer to the [Burk Firmware Loader Manual](#) for detailed instructions on uploading firmware to the Plus-X ICRU.

## Getting Help

For technical support, please email [support@burk.com](mailto:support@burk.com) or call our direct technical support line at 978-486-3711. We will be glad to assist you. The technical support office is open Monday – Friday, 9AM to 5PM Eastern time.

## Warranty

Burk Technology, Inc. warrants the Plus-X ICRU to be free of defects in materials and workmanship for a period of 24 months from the date of purchase. Equipment will be repaired or replaced at the option of Burk Technology and returned freight prepaid to the customer. Damage due to abuse or improper operation or installation of the equipment or caused by fire or flood or harsh environment is not to be covered by this warranty. Damage in shipping is not the responsibility of Burk Technology. A return authorization must be obtained before returning any equipment. Materials returned under this warranty must be shipped freight prepaid and insured in the original shipping carton or suitable substitute to Burk Technology, Inc., 7 Beaver Brook Road, Littleton, MA 01460. Repairs not covered under this warranty will be made at prevailing shop rates established by Burk Technology.

THE WARRANTY SET FORTH ABOVE IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. BURK TECHNOLOGY, INC. SHALL NOT BE LIABLE TO ANY PARTY FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF THIS EQUIPMENT.

## Appendix A: Specifications

### Dimensions:

1.75" (4.45cm) H

19" (48.26cm) W

12" (30.48cm) D

### Operating Temperature:

0° to 40° C;

### Humidity:

5 to 85% RH

### Power Requirements:

100 to 240VAC, 47–63Hz, 1A;

Power entry module with standard, grounded power cord supplied;

1A fuse protection

### Connectivity:

Ethernet connection to ARC Plus

### Channel Capacity:

16 relays (individual or up to 8 raise/lower pairs)

### Output Types:

C, NO, NC relay outputs;

momentary or latching;

5A, 240VAC